

Hoist Help Guide

This hoist is intended for lifting children and adults up to 200kg. This equipment must not be used for any other purpose.

2 Pre use checks:

Hold and pull the carry bar, moving the hoist to an area free of obstructions. Take care to familiarise yourself with the functions and controls (see Fig 1).

3 Instructions for use:

The hoist is controlled via the hand control (see Fig 2). Do not pull the hand control with force. When the hand control is not in use, clip over the carry bar. Keep all obstructions clear during lifting.

4 Slings:


This hoist is designed for use with loop style slings only. If unsure do not use your sling.

5 Trouble shoot:


If the hoist is not working check to see if the emergency stop cord has been pulled into the down position, disabling the hoist (see Fig 3).

To re-enable push white clip, attached to the top of the red cord, up toward the hoist. If unable to reach use the carry bar.

Figure 1.



**Changing Places
Transforming Lives**



6 Emergency lowering:

If the hoist becomes stuck or won't lower, pull the red cord and lower to the desired height. Use this function only in an emergency as it can lead to permanent hoist damage if the limit switches are overridden. If the hoist begins to raise, stop immediately and contact Mandurah Visitors Centre or call 9550 3777

**Need Assistance? Call City of
Mandurah all hours 08 9550 3777.**